


WIRING DIAGRAMS **Fig. 3: Fuse Block (Grids 8-11)** 1987 BMW 528e

For DIAKOM-AUTO <http://www.diakom.ru> Taganrog support@diakom.ru (8634)315187
 Copyright © 1998 Mitchell Repair Information Company, LLC
 Friday, November 03, 2000 03:49PM



FUSE NUMBER & AMP CHART

FUSE NO	AMP	FUSE NO	AMP
1	16	10	8
2	8	11	16
3	8	12	8
4	25	13	16
5	8	14	25
6	8	15	8
7	8	16	8
8	8	17	25
9	8		